

# Custom Dynamics®

## TruFLEX® Integrated LED License Plate Frame Wiring Instructions

- 1) Mount license plate frame in desired location. You may need to notch license plate to allow for wires to pass through, use heat shrink to protect wires from any sharp edges on plate frame.
- 2) Use the diagram below to connect TruFLEX® dual converter to Red center TruFLEX® . This will allow TruFLEX® to function as running and brake.
- 3) Connect Orange Wire from TruFLEX® dual converter to bike's running light wire
- 4) Connect White Wire from Plate Frame to bike's running light wire.
- 5) Connect Red Wire from TruFLEX® dual converter to bike's brake light wire.
- 6) Connect All Black Wire(s) from TruFLEX® and Plate frame to bike's ground.
- 7) Connect right side Amber TruFLEX® Yellow wire to bike's right side turn signal wire.
- 8) Connect left side Amber TruFLEX® Yellow wire to bike's left side turn signal wire.

TruFLEX® Dual Converter Wiring Diagram



### Installation Instructions for Dual Converter:

