

Items Supplied >

- 1 – Front Muffler
- 1 – Rear Muffler

Application >

SUZUKI INTRUDER 1400 87-04
SUZUKI S83 05-09

Instruction Manual >

3165TSSC

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

1. Remove the stock mufflers and head pipes.
2. Install gaskets into the mufflers.
3. Reinstall stock head pipes and **FINGER TIGHTEN.**
4. Install stock muffler clamps onto the mufflers using stock hardware.
5. Install left and right mufflers, bolting them into place **FINGER TIGHTEN.**
6. Tighten head pipes making sure mufflers are properly aligned and not in any kind of bind.
7. Tighten muffler clamps then tighten rear muffler mounts.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-3165.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*