

Joker MACHINE

TRIUMPH IGNITION RELOCATION BRACKET INSTRUCTIONS

PART NO. 09-070 to 09-073

For technical support contact Joker Machine

2245 Kiowa Blvd N. Ste. 100, Lake Havasu City, AZ 86403

PHONE: 909-596-9690, FAX: 909-596-9693

sales@jokermachine.com, www.jokermachine.com

1. Mount the Joker Machine Ignition Relocation Bracket to the frame tube with an M8 Allen wrench, and using blue Loctite (medium strength thread locker) on screws.
2. Remove ignition switch from bracket ear.
3. Route enough wire to mount the ignition switch to the Joker Machine bracket on frame tube.

NOTE: If there isn't enough wire, re-route the ignition switch wire under the tank. Then zip-tie excess wire to the frame under the tank.

4. Install ignition switch to Joker Machine bracket using blue Loctite on M5 screws. For **Scramblers** use the (2) M5x12 button head screws Joker provides instead of the stock ignition switch screws.

